

## Instruction of How to Clear Secure Code

You can ONLY clear Secure Code while Cold Start.

- 1) Hold down key <A>, and then switch on the power supply, (or press the reset button).
- 2) Release the key after about 3 seconds, and the cold start screen will be shown as below:-

<b>MAST</b>	<b>ENG.</b>	<b>CARD</b>	<b>DISP</b>
<b>CARD</b>	<b>CARD</b>	<b>TYPE</b>	<b>TYPE</b>

- 3) Please do setup as usual, such as Master Card and etc.
- 4) Press <#> key from the main screen, and the display will show the remaining 4 commands of the set up menu, that is:-

<b>EL2K</b>	<b>Con</b>	<b>Crd</b>	<b>clr</b>
<b>Mod</b>	<b>Swip</b>	<b>Siz</b>	<b>sec</b>

- 5) Press <D> key in order to clear the secure code. The display will show:-

<b>PC Serial Code</b>	
<b>Clear</b>	<b>No</b>

- 6) Press <D> key to select <YES>, ending with <#> key to return to the main menu screen.
- 7) After finishing the above set-up, you should press <\*> key from the main screen to exit.
- 8) The date/time should appear on the LCD and the red light on the reader should begin to flash.
- 9) Open software EdotWin or WinPro and make sure the communication is working fine.